

Constellation X-ray Mission
Spectroscopy X-ray Telescope:
Full-shell optics development and evaluation

Steve O'Dell
NASA Marshall Space Flight Center

Constellation-X
Technology and Project Status meeting
NASA Goddard Space Flight Center
Greenbelt, Maryland
2000 January 21

Development and evaluation tasks

Mandrel fabrication

Design

Nickel plating

Diamond turning

Polishing

Procurement

Surface preparation

Optical coating

Separation mechanics

Shell technology

Material & process

Structure

Bonding

Mounting

Evaluation

Metrology

Performance prediction

X-ray testing

Goals for 2000

- Mandrels
 - With Project, evaluate cost and schedule for production mandrels.
 - With Project, begin acquisition of meter-class precision mandrel.
 - Start modification of infrastructure to handle meter-class mandrels.
- Optics
 - Meet metrics for 0.5-m-diameter optics.
 - Replicate 1-kg optic to meet flight-weight requirement.
 - X-ray test optic to meet 10-arcsec-HPD allocation.
 - Develop integral stiffening structures.
 - Start modification of infrastructure to handle meter-class optics.
- Assembly
 - Conduct trade study of where to provide stiffness (optic or mount).
 - Develop and investigate concepts for alignment and assembly.

Replicated-optics challenges

- Mandrel fabrication
 - Requirements
 - $< 5''$ geometric half-power diameter (HPD_{geom})
 - $< 5\text{-\AA}$ surface finish for spatial frequencies $> 1 \text{ mm}^{-1}$
 - Need mandrels up to 1.6-m diameter (1.0-m length, tentatively).
 - Carl Zeiss (Germany) has demonstrated capability up to 0.7 m .
 - MSFC is refining fabrication/metrology to achieve capability.
- Shell technology
 - Requirements
 - Reduce mass to $1/6$ that of demonstrated technologies (*XMM*).
 - Maintain figure and finish during separation from mandrel.
 - Developed two key shell technologies.
 - Developed high-microyield-strength (nonductile) nickel alloy.
 - Identified robust overcoat to control surface adhesion.

Mandrel status

- Small mandrels for process development
 - Diamond turned and polished dozens of 3-cm cone mandrels.
 - Have a few 6-cm (Wolter-1) mandrels for shell-technology research.
- Medium mandrels for replication
 - 25-cm (Wolter-1) 2-piece mandrel
 - Will use for non-integral-shell experiments with existing carriers.
 - Mandrel has poor figure; may need to repolish or replace.
 - 50-cm (Wolter-1) mandrels
 - Have one pathfinder mandrel for process qualification.
 - MSFC fabricated one precision mandrel (10-arcsec HPD).
 - Project purchased two precision mandrels (5-arcsec HPD) from Zeiss.
- Large (meter-class) mandrels
 - Project is investigating purchase of meter-class mandrels.

Infrastructure status for meter-class optics

- Coating
 - Large coating chamber is operational and in use.
- Plating
 - Medium plating bath is contracted and in use.
 - Large plating facility will be completed by 2000 Spring.
- Separation
 - Medium separation fixture is operational and in use.
 - Meter-class optics will require new separation system.
- Metrology
 - Vertical Long-Trace Profilometer is operational and in use.
 - Are working to improve accuracy and repeatability.
 - Meter-class mandrels will require some modification.
 - Are conducting a more thorough inventory of meter-class readiness.


Shell processes under investigation

- Integral shells (led by MSFC)
 - Electroformed high-strength nickel alloys, at MSFC
 - Low deposition temperature and dimensionally stable
 - Low residual stress and low cost
 - No plastic deformation of new alloy, allowing thin walls
 - Lightweighting by electroforming ribbed, thin-walled structures
 - Plasma-sprayed ceramics, with Plasma Processes Inc.
 - Lightweight optics, even with uniformly thin shell
 - Low cost; also suitable for near-net-shape nonintegral shells
- Nonintegral shells (led by SAO)
 - CVD silicon carbide, with Morton Advanced Materials
 - Lightweight optics, even with uniformly thin shell
 - Fiber-reinforced plastics, with Composite Optics Inc.
 - Very lightweight optics, even with uniformly thin shell

Shell-technology status

- Have identified and successfully used passivation coating.
 - Encountered problems, primarily due to inadequate cleaning.
- Have developed various high-strength nickel-alloys.
 - A glass-like (nonductile) alloy gives highest microyield strength.
 - Have achieved low stress sensitivity, but slightly compressive.
 - A slightly ductile alloy may give adequate microyield strength.
 - Have achieved low stress sensitivity, at near-zero stress.
 - Have reduced variation in current density across mandrel.
- Are resuming research in plated structures.
 - Integral structures will stiffen thin-walled optics.
 - Alternative is to provide stiffness through mounting.
- Are investigating techniques for cutting to length.
 - Eliminates end effects (stress and pitting); allows focus adjustment.

Plating-stress sensitivity of glassy nickel



- Reduced variation of residual plating stress across shell.
 - Reduced sensitivity of plating stress to current density.
 - Reduced variation of plating current density across mandrel.

Electroforming on MSFC 0.5-m-diameter mandrels

- MSFC pathfinder mandrel (50M3).
 - Have used and continue to use for process qualification.
- MSFC precision mandrel (50M1) — HPD \approx 10-arcsec.
 - Replicated (1999 May) a 4-kg shell. (Flight weight is about 1 kg.)
 - X-ray tested (1999 May).
 - Variations in plating stress caused degraded performance.
 - Replicated (1999 May) a 2-kg shell for display.
 - Replicated (1999 Nov-Dec) three 1-kg (flight-weight) shells.
 - Broke two in separate handling incidents after separation.
 - X-ray tested (1999 Dec) unbroken shell.
 - Poor mounting to stiffening ring (0.25-mm-amplitude variations in bond line) severely degraded performance.
 - Have debonded shell and remounted on stiffening ring, with mandrel as holding form.
 - Will conduct metrology (2000 Jan) and x-ray test (2000 Feb).

Plans for Zeiss 0.5-m-diameter mandrels

- Zeiss precision mandrels (50Z1 and 50Z2) — HPD < 5 arcsec.
 - Project ordered (1998 Oct) and received (1999 Aug) 2 mandrels.
 - At time of order, MSFC had not produced a precision mandrel.
 - Project will use one for segmented and nonintegral-shell optics.
 - Will use other (primarily) for integral full-shell optics.
 - Have built interface hardware for metrology; are building interface hardware for full-shell optics production.
 - Plan to replicate and x-ray test 1-kg (flight-weight) optic.
- Issues in first use of Zeiss mandrels
 - Minimize potential for damage to these high-quality mandrels.
 - Resolve degradation of passivation coating on 50M1.
 - Determine how to remove residual gold (for segment replication).
 - Verify processes on 50M3 (pathfinder) or 50M1 first.
 - Complete fabrication of interface hardware.

Issues for full-shell SXT optics

- Shells
 - In principle, electroformed nickel alloys should meet requirements.
 - Material is strong and plating-stress variations are low.
 - Have already electroformed 3 flight-weight shells.
 - Still need to demonstrate required optical performance.
 - Other materials may save weight or provide higher stiffness.
 - Residual stress will probably necessitate non-integral approach.
- Mandrels
 - Size and weight considerations make scale-up a technical concern.
 - Identify specific problems; seek solutions and alternatives.
 - Cost and schedule are a programmatic concern.
 - Identify requirements for long-lead-time infrastructure.
- Alignment and assembly
 - Evaluate trade between stiffness in shell or in mount.