



## **Choice of Blocking Filter Issues: Lexan vs. Aluminized Polyimide**

### **Aluminized Polyimide yields**

- Factor of 6-7 lower effective area below 0.3 keV
- O and N edge
- Stronger
- Less water permeability issues
- Mesh vs. no mesh option results in 20-30% difference in effective area above 1 keV



## Some observations...

- **Below 0.6 keV**, grating is the instrument of choice. Both effective area and resolution of the grating are better than that of the microcalorimeter.
- **0.6--1 keV**, calor has a resolution of 300 or better and larger effective area than the grating. Depending on the science goals, both could be the instrument of choice.
- **Above 1 keV**, the calor has substantially better effective area and resolution and is the instrument of choice. Above 1 keV, the grating is useful for cross calibration with calor.
- In lieu of the loss of substantial effective area below C edge for calor, it is most beneficial to move down the energy range of the grating by **0.1 keV** (if possible) for the following reasons...

# Science areas that would benefit from lower energy effective area...

- High Redshift Universe

AGN/QSO/Starburst

Clusters

Fe L falls around  $E \sim 0.25$  keV for  $z \sim 2$  objects

- Galactic Halos at moderate redshift

C edge at  $E \sim 0.18$  keV for  $z \sim 0.7$  objects

- Solar System science

Energy down to 0.1-0.15 keV needed

