

# **Integral shell mirrors for the Constellation X-ray Mission Hard X-ray Telescope**



**P. Gorenstein, A. Ivan, R. J. Bruni, S. E. Romaine**  
Harvard-Smithsonian Center for Astrophysics



**F. Mazzoleni, G. Pareschi, M. Ghigo, O. Citterio**  
Osservatorio Astronomico di Brera (Italy)

*Constellation-X HXT*

# Integral (Whole Shell) Electroformed Nickel Optics

## Advantages

- Based upon proven technology, i.e. SAX, JET-X, XMM
- Best angular resolution, XMM achieved 15 arcsec HPD
- Smallest number of elements to assemble, by over order of magnitude


## Challenges

- Difficult to apply multilayer coatings to interior of closed shell
- Nickel substrates are heavier than glass or aluminum, reduce mass
- Expensive beginning because a “superpolished” 360 deg mandrel is needed for each shell
- Smoother (cp XMM) replica surface required


*Constellation-X HXT*

# Significance of Better Angular Resolution


- Higher Sensitivity, most measurements will be background limited, 15 arcsec resolution telescope is 4x more sensitive than 1 arcmin telescope
- Imaging, spatially resolved spectroscopy
- Avoiding confusion



Cas A, True Color




M31, Central 1 arcminute



M82, 1.5 arcminute

*Constellation-X HXT*

# Electroformed Integral Shell Telescope



SAX mirrors. For JET-X, XMM, and Con-X HXT, scale up the dimensions and increase number of shells

*Constellation-X HXT*

# Two Methods of Applying Multilayer Coatings

## HXT Range of Shell Diameters is 10 to 40 cm

- For shell diameters 16 cm or larger, coating is deposited upon the replica by DC magnetron sputtering, - being studied by **SAO**
- For shell diameters  $< 16$  cm, coating is deposited upon the mandrel and transferred to the replica upon separation, - being studied by **OAB**

*Constellation-X HXT*

# SAO Multilayer Deposition Facility


**Capable of coating large area:**

- Flat substrates
- Segmented substrates
- Interiors walls of cylinders with 15 to 40 cm diameter
- Outer surface of cylinders




*Constellation-X HXT*

# Measurement of Hard X-ray Reflectivity of 300 Period Graded d-Spacing Multilayer at BNL (SAO)



*Constellation-X HXT*

## Measurement of Sample of Replica from SAX Mandrel with 10 Uniform Period Layers at the Panter Facility (OAB)



Multilayer Was Transferred Directly from Mandrel to Replica

*Constellation-X HXT*



# OAB “Superpolisher”


- **Currently Polishing  
Mandrel Provided by SAO**
- **Capable of Polishing Flats  
and Cylinders to 2 Ang. Rms**



*Constellation-X HXT*


# **Mandrel, 28 cm Diameter**

Fabricated by SAO (commerically), being “superpolished” at OAB



*Constellation-X HXT*

**Replica, 28cm D.**  
(Mandrel Not in Final State of Polishing)



**Delivered by OAB, to be coated at SAO soon**

*Constellation-X HXT*

## Near Term Goals

SAO

SAO + OAB

OAB

Coat current replica with  
250 graded bi-layers

Complete polishing  
of mandrel

Coat flats with multilayers

- Polished fused silica (“gold standard”)
- Electroformed (real material)

Measure X-ray reflectivity of replica (pencil beams) BNL (May) and/or ESRF (June)

Coat 2nd replica provided by OAB  
with depth graded multilayers

Media Lario to produce 2nd  
replica with smoother finish

- More polishing by OAB
- Refinement in electroforming

Measure full aperture angular resolution of current replica at MSFC

*Constellation-X HXT*