


SXT Mirrors Manufacturing

Will Zhang

Laboratory for High Energy Astrophysics


Goddard Space Flight Center

Specifications




- Operating temperature range: 1 degree C
- Axial slope error: $< 2''$ RMS
- Roundness: $< 5 \mu\text{m}$
- Bottom Edge: $< 25 \mu\text{m}$ deviation from plane perpendicular to optical axis
- Microroughness: < 4 angstroms (RMS)
- Thickness: $400 \mu\text{m}$ (glass) + $40 \mu\text{m}$ (epoxy) = $440 \mu\text{m}$
====> 280 kg per mirror assembly (417 kg allocation)

Slumping Substrates



- Schott D263 glass sheets (400 μm)
- Conical mandrel made of fused silica: maximum deviation from Wolter-I mandrel less than 2 μm
- Substrate ripples: $< 0.5 \mu\text{m}$ RMS
- Maximum deviation from forming mandrel: $< 2 \mu\text{m}$


Comparison of a Substrate and Its Forming Mandrel



Epoxy Replication



- Replication mandrel: Wolter-I's made by Zeiss, Axial error $\sim 1''$ RMS
- Epoxy sprayed ($40\text{ }\mu\text{m}$) on substrate
- Mandrel and substrate mated in vacuum
- Epoxy cured at temperature <40 degrees C
- Separation from the mandrel



State of Knowledge

- Slumping process does meet requirements:
 $P-V < 2\mu\text{m}$ and $\text{RMS} < 0.5\mu\text{m}$
- Glass edges can be cut to be free of fractures
- Replicas resemble the mandrel to better than 3" RMS (small mirrors) and ~6" (large mirrors)
- Epoxy application and the substrate/mandrel mating are crucial in making good replicas
- Replica-Mandrel separation process introduces temporary distortions which relax over a period of several days

Plan for Next Year

- Acquire satisfactory forming mandrels (March 2002):
Roundness error $< 5\mu\text{m}$
Straightness P-V $< 2\mu\text{m}$
- Improve slumping environment to reduce ripples $< 0.5\mu\text{m}$ (December 2001)
- Design and fabricate a precision glass cutter to meet requirements on bottom edge (April 2002)
- Improve epoxy application techniques to ensure better uniformity and control (January 2002)
- Improve replica-mandrel separation technique to minimize distortion (December 2001-January 2002)
- Next replication will take place March 2002