

X-Ray Microcalorimeters



FST Meeting
Smithsonian Astrophysical Observatory
September 18, 2002



Agenda

Introduction and Overview Richard Kelley (GSFC)	5 min
Progress on NTD Microcalorimeters Eric Silver (SAO)	20 min
Progress on TES Microcalorimeters Enectali Figueroa (GSFC) & Steve Deiker (NIST)	40 min
Progress on Magnetic Calorimeters Christian Enss (Brown University)	10 min



Astro-E2/XRS Microcalorimeter Array


Baseline array for Astro-E2/XRS:


2 x 16 "bilinear" array Rectangular pixels 12 eV resolution

Have two bilinear arrays that have successfully passed acceptance testing.

Possibility of square array with higher spectral resolution.

New design also offers many other benefits.








Significantly Improved Energy Resolution

Energy resolution is close to theoretical limit of ideal detector and about a factor of 2 times better than bilinear array.

Factor of 2 improvement allows Fe-K lines, a key diagnostic for Astro-E2, to be almost fully resolved.

Extends diagnostic capabilities to lighter elements, and improves sensitivity to trace elements and velocity measurements.





Summary of Benefits of Adopting 2-D Array

Elimination of 1/f noise gives x 2 higher spectral resolution Faster pulse response gives x 2 higher margin against pulse-pileup Improved resolution uniformity for easier calibration and data analysis Improved mechanical margins against crack initiation in Si Fully-covered pixels effectively extends spectral band to lower energies Two order of magnitude improvement in detector heat sinking Improved in-flight calibration system increases instrument sensitivity Better match to x-ray optics for increased photon detection efficiency

Working with NASA HQ to facilitate implementation




Detector Requirements


Top-Level Requirement		Derived Requirement
Energy Resolution	R=3000 from 6 to 8.5 keV (2 eV at 6 keV)	same
Pixel Size	1/3 of HPD	15" HPD ⇒ 5" ∴ 250 μm
Field of View	2.5 arcmin	30 × 30 array
Detection Efficiency	Provide top level A _{eff}	TBD, but approximately: QE > 90% at 6 keV array fill factor > 90%
Counting Rate	"handle" up to 1000 cps/pixel	$τ_{eff}$ = 100 - 300 μsec




TES Array Concepts




NIST Idea:








NTD Ge Microcalorimeter Array





Calorimeter Technology Roadmap




R.L. Kelley



Supplemental Material



X-ray Microcalorimeter





Overall Status

Thermometer Types:	Energy Resolution
Al/Ag, Mo/Au, Mo/Cu TES	2.0 - 2.5 eV at 1.5 keV
NTD Ge semiconductor	4 - 6 eV at 6 keV

Array Size

Only single pixel *test results* thus far (but small arrays have been fabricated)

Counting rate

Pulse decay time constants of ~ 300 μsec

Readout Schemes

32 channel XRS system, analytical designs for larger JFET systems; MUX designs and functional systems for IR TES.

For TRL-6, we need to demonstrate

- 2-4 eV at 6 keV (and below) with high degree of pixel-pixel uniformity
- Robust array scheme with high-yield process.
- Faster pulses (< 300 μsec)
- Large array readout schemes compatible with extended life mission.




Recent Progress and Issues

GSFC:

Electrical contact to TES.

Poor step coverage with sputtered Nb leads.

Have several recovery approaches; Aluminum leads are working, but we need to pursue a robust solution.



Undercutting of bilayer


Produced TES protection mask to protect Mo during certain etch steps.


Pin hole defects in Au layer of bilayer Solved problem with tungsten crucible w/Ta pellets.

Bilayer thickness optimization


Continuing studies w.r.t. heat capacity, R_{normal}, I_{critical}; demonstrate reproducibility.









Impedance measurements yield device parameters:










4-channel, 2-stage SQUID readout Installed in dilution refrigerator


SQUID Array

Detector Box

1st stage SQUID board

Detect board








NIST:

Complete fabrication of 8x8 array of TES detectors using MEMS structures for the four-pixel demo.

Two of the inner 8-pixel columns and the inner four pixels are instrumented with electrical leads. Under-pixel wiring layers are not yet implemented. If it works, an array like this would be used in the NIST four-pixel demo.

Array chips were fabricated both with and without Bismuth absorbers. Single pixels from the arrays will be tested over the next month. A photograph of a completed 8x8 array:





Tested new, dedicated superconducting bilayer deposition system. Fabricated films with target transition temperatures of close to 100 mK. Demonstrated run-to-run and across-wafer transition temperature variation of $<\sim 5$ mK (1 σ).

Recently commissioned a second ADR for array testing. Now commissioning a third ADR for fast-cycling screening and measurements of transition temperature.

Progressing toward increasing bandwidth of TES MUX electronics from 3 MHz to 50 MHz.



NTD work at SAO:

Four preamplifiers were fabricated and tested successfully


The 2-stage ADR for the 4 pixel demo is under construction

Have built some new devices with a thin layer of gold on the tin absorber to test the thermalization properties

We are investigating the effects of impurities in the tin absorber to improve the reproducibility of the temporal response of the detectors




TES 2x2 Demo Schedule





Preliminary TES 2x8 Demo Schedule






TES TRL-6 Costs (\$K in FY02)

Development Area	FY03	FY04	FY05	
Thermal Conductance & Cross talk	137	0	0	137
Noise	193	0	0	193
Basic process, materials, and integration	735	946	922	2,603
Absorber Development	103	0	0	103
Electrical Cross Talk	73	0	0	73
Micro-vias and Interconnects	139	235	237	611
SQUID and MUX Chips	350	350	350	1050
MUX and Digital Processing Electronics	414	435	363	1212
Radiation Environment Studies	74	160	249	483
Thermal Staging/Detector Assembly	178	215	155	548
Wiring and B-field Shielding	50	51	52	153
2 x 8 and 3 x 32 demonstrations	143	429	243	815
Total required funding: Total required from Con-X project:	2,589 2,019	2,821 2,521	2,571 2,571	7,981 7,111



NTD Germanium Microcalorimeter Development (revised August 13, 2002)



Single pixel optimization is being carried out using SR&T funds



NTD Budget for FY2003

Budget Summary for Research Proposal

Year 2
Total Period of Performance from October 1, 2002 to September 30, 2003

NASA USE ONLY

Α

С

1. Direct Labor (salaries, wages, and \$136,476 fringe benefits.)

2. Other Direct Costs:

a. Subcontracts	289,120
b. Consultants	0
c. Equipment	49,920
d. Supplies	87,7 <mark>2</mark> 4
e. Travel	5,412
f. Other	37.037

3. Indirect Costs 71,800

4. Other Applicable Costs 0

5. Subtotal -- Estimated Costs 677,489

6. Less Proposed Cost Sharing (if any)

7. Carryover Funds (if any)

a. Anticipated amount:

b. Amount used to reduce budget

8. Total Estimated Costs \$677,489



TES Milestones, continued

FY04

Design detector front-end assembly Build up test platform for 3 x 32 demo

FY05

Build and qualify 32 x 32 array

- individual pixel performance
- perform component vibration
- repeated thermal cycle evaluation

Perform 3 x 32 demo on 32 x 32 array

Demonstrate viable interconnect scheme for 32 x 32 array

Design particle rejection scheme

Design flight-worthy FEA



TRL-6 Definition

TRL 6 definition:

system or sub-system prototype demonstration in relevant environment

System:

Full-sized calorimeter array with cold and warm electronics. Full 32 x 32 read-out not necessary, but the extension from 3 x 32 to 32 x 32 must be possible through replication of existing hardware, and not further development.

Relevant environment:

Operation in an ADR (relevant magnetic environment), but not necessarily a Con-X flight ADR design.

Vibration and thermal cycle tests to be done at the component (calorimeter array) level.



TES Milestones

FY02

Determine baseline compact pixel design.

Study thermal cross talk and determine baseline array structure.

Incorporate "mushroom" absorbers with appropriate heat capacity onto compact pixels and evaluate thermalization performance.

Build up test platform for 2 x 8 demo.

Complete study of L2 radiation environment and impact on focal plane array and basic irradiation tests.



TES Milestones, continued

FY03

Determine baseline absorber design for TRL-6 demo

Determine baseline TES design for TRL-6 demo

Develop MUX and digital processor capable of reading out 2 x 8 demo


Complete electrical system model to understand susceptibilities to cross talk and pickup


Build and qualify 8 x 8 array

- Individual pixel performance
- perform component vibration
- repeated thermal cycle evaluation


Perform 2 x 8 demo on 8 x 8 array


$500 \times 500 \mu m$ TES on 5 mm membrane





300 x 300 µm TES on 3 mm membrane







GSFC




Testing Pixels with Con-X size








Individual TES devices designed to have different thermal conductance to allow parameterization.



GSFC





Results from Compact TES Pixels






TES Fabrication Examples








Array of identical 150 micron devices. Soon will make these with 250 and 400 micron "mushroom" absorbers. The Bi absorbers shown are the size of the stem in the mushroom.




Micromachined Bi Absorbers


Proof of concept for fabricating x-ray absorbers in array format with high filling factor.



32 x 32 array of
Bi absorbers


300 µm "pixels"








SQUID Multiplexer Scheme




NIST/Boulder



SQUID Multiplexer



- 32-channel MUX. (Need 32 chips to instrument kilopixel array.)
- First-generation MUX deployed in astronomical instrument (FIBRE) with GSFC
- Second generation improves crosstalk & power



- Switched digital feedback is working
- Can sample at 1.6 MHz line rate
- Sufficient performance for 2 × 8 demo array
- Need to increase bandwidth for full instrument
 NIST/Boulder



NTD Calorimeter with Sn Absorbers

