

LLNL Status


May 1, 2002

Joel Ullom

Lawrence Livermore National Laboratory


Frequency Domain Multiplexing

- Use AC sensor bias. Each pixel has identifying frequency
- Photons reduce bias envelope



- We are multiplexing calorimeters designed to measure gamma-rays
 - resolution ~ 60 eV at 60 keV
 - fall time = 1 ms
 - area = 1 mm²


Multiplexing Circuit



In 2D array, bias by row, read by column

Two sensor multiplex

measured spectral density



resolution
summary

${}^2E_{\text{FWHM}}$	device #1	device #2
only recipient of bias	65 eV	62 eV
both sensors biased	63 eV	65 eV
both biased, coincident pulses	64 eV	63 eV

energy resolution unaffected by multiplexing