

Development of Mirror Segments for Constellation-X

Will Zhang

Laboratory for High Energy Astrophysics
Goddard Space Flight Center

Technical Requirements

Fabrication Process

Substrates

Requirements

Status

Replication

Requirements

Status

Immediate Future

Specifications of Mirror Segments

1. Mass: Areal density less than 1.5 kg m^2
 - Glass thickness $< 600 \text{ }\mu\text{m}$
 - Current Baseline: $400 \text{ }\mu\text{m}$
2. Dimension:
 - 60° segments for inner shells
 - 30° segments for outer shells
 - Axial Height: $\geq 20\text{cm}$
 - Smallest mirror segment: $21\text{cm} \times 20\text{cm}$
 - Largest mirror segment: $42\text{cm} \times 20\text{cm}$
3. Figure (spatial frequency 0.3 to 200mm):
 - Axial slope RMS error $< 2''$
 - Circularity error $< 10\mu\text{m}$
 - Average radius error $< 100\mu\text{m}$
 - Average slope (cone angle) error $< 30''$
4. Microroughness (spatial frequency 1 to 300 microns):
 - 6\AA RMS (1-300 μm)

Home

Fabrication Process

- **Substrate Fabrication**
 - **Material:** Schott D263 glass sheets
 - **Forming Mandrel:** conical in shape, relatively coarse in figure, and inexpensive
 - **Forming Process:** heating cycle and glass sheets conform to the shape of the mandrel under gravity
- **Replication**
 - **Replication Mandrel:** Precision figured and polished ZeroDur Wolter-I
 - **Replication Mandrel Coating:** Au
 - **Epoxy Application on Substrate:** 40 μ m for now and 10 μ m in future
 - **Mating:** Epoxy-coated Substrate and Au-Coated Replication Mandrel are placed together in vacuum to avoid air pockets



Home

Specifications of Substrates

- **Overall Figure:** conical in shape, forming mandrel being the conical approximation of the corresponding Wolter-I geometry
- **Tolerances:**
 - Cone angle: $\pm 20''$
 - Axial Straightness: $\pm 2\mu\text{m}$
 - Roughness: $\sim 20\text{\AA}$ RMS
 - Roundness: $\pm 5\mu\text{m}$

Home

Quality of Formed Substrates



- Excellent substrates are being formed. They deviate from the forming mandrel by no more than $1.5\mu\text{m}$
- They are essentially perfect for use with replication with an epoxy thickness of $\sim 10\mu\text{m}$


Home

Requirements on Replication Process

- It has to bridge the gap between the quality of the substrate and the final requirements on the mirror segment
- The epoxy layer has to be **thick** enough to smooth out the irregularities of the substrate **and** to create the necessary Wolter-I curvature
- The epoxy layer also has to be **thin** enough to reduce temperature sensitivity of the finished replica to an acceptable level.
- Present Baseline Epoxy Thickness: 10 to 20 μm

[Home](#)

Quality of Renplication



- Figure on left: Height (or relative radius) errors of a replica
- Figure on right: Slope errors of the same replica
- This is one of the best replicas that have been done so far. It demonstrates the potential of the epoxy replication technology. More work is needed to achieve consistency and increase yield.

Home

Immediate Plan

- Form segments that are 20cm in axial length and 50cm in diameter using forming mandrels that just arrived last week
- Replicate the segments off a 50-cm diameter mandrel fabricated by Zeiss
- Demonstrate that mirror segments meet requirements by end of 2002

[Home](#)